


User Manual

Suitable for all low-voltage battery packs from DUBAK



Empowering Your Clean Energy, Together!

- [1.Instruction](#)P01
- [2 Important Safety Warning](#) P02
 - [2.1 Before Connecting](#) P03
 - [2.2 During operation](#) P04
- [2.Unpacking & Overview](#) P04
 - [3.1 Packing List](#) P04
 - [3.2 Product Overview](#) P05
- [3.Installation](#) P06
 - [4.1 Selecting Mounting Location](#) P06
 - [4.2 Mounting The PACK](#) P07
 - [4.3 Connection and Communication](#) P09
- [Appendix 1 : BMS paramete](#) P13
- [Appendix 2 : Parallel Connection](#) P15
- [Appendix 3 : Host soft operation](#) P16
- [Appendix 4 : Wifi&Bluetooth](#) P17
- [Appendix 5 : Trouble shooting](#) P18

Note: please comply with all warnings and operating instructions in this manual strictly. Save this manual properly and read carefully the following instructions before installing the unit. Do not operate this unit before reading through all safety information and operating instructions carefully.



Warning



Recyclable.



Read instruction before use.




Do not dispose battery in household trash.



1. Instructions

The Energy storage pack is an essential component of the photovoltaic power generation system. It can provide electricity for the connected load, and it can also store photovoltaic solar modules, fuel generators, or wind energy generators by charging the remaining energy in case of emergency. When the sun goes down, energy demand is high, or there is a power outage, you can use the energy stored in the system to meet your energy needs at no additional cost. In addition, the energy storage Pack can help you achieve energy self-consumption and ultimately achieve the goal of energy independence.

According to different power conditions, the energy storage PACK can output power during peak power consumption, and can also store energy during low power consumption. Therefore, when connecting the matching photovoltaic modules or inverter arrays, external equipment is required to match the energy storage the working parameters of the pack to achieve the highest operating efficiency. For a simple diagram of a typical energy storage system.



Energy storage System Overview

It is very important and necessary to read the user manual carefully before installing or using the battery. Failure to follow any of the instructions or warnings in this document can result in electrical shock, serious injury, death, or may damage the battery and the whole system.

- If the battery is stored for a long time, it is requirement that they are charged every three to six months, and the SOC should be no less than 90%, after fully discharging, The battery needs to be recharged within 12 hours.
- Do not expose cable outside; Do not use cleaning solvents to clean the battery.
- All battery terminals must be disconnected before maintenance.

2. Important Safety Warning



- Do not expose the battery to flammable or harsh chemicals or vapors.
- Do not paint any part of the battery, include any internal or external components.
- Do not connect battery with PV solar wiring directly.
- Any foreign object is prohibited to be inserted into any part of the battery.
- Our company will not bear any warranty claims for direct or indirect damage caused by violation of the above items.



2.1 Before connecting

- After unpacking, please check the battery and pack list first, if the battery is damaged or spare parts are missing, Please contact the dealer.
- Before installation, be sure to cut off the grid power and make sure the battery is in the turned-off mode;
- Wiring must be correct, do not mix-connect the positive and negative cables, and ensure no short circuit with the external device;
- It is prohibited to connect the battery with AC power directly;
- The BMS in the battery is designed for 12VDC/24VDC/48VDC, DO NOT connect battery in series;
- It is prohibited to connect the battery with different type of battery;
- Please ensure the electrical parameters of battery system are compatible to inverter, Keep the battery away from fire or water.

Necessary installation Tools.


| | | | |
|--------------------|-----------------|---------------------|----------------------|
| | | | |
| Clamp meter | Multi-meter | Label paper | Phillips screwdriver |
| | | | |
| COAX crimping tool | Diagonal pliers | Wire stripper | Claw hammer |
| | | | |
| Hammer drill | Insulation tape | Cotton cloth | Brush |
| | | | |
| Heat shrink tubing | Heat gun | Electrician's knife | Protective gloves |

Personal protective equipment

| | | | |
|------------------|----------------|--------------|--------|
| | | | |
| Insulated gloves | Safety goggles | Safety shoes | Helmet |



Necessary installation environment



2.2 During operation

- If the battery system needs to be moved or repaired, the power must be cut off first and the battery is completely shutdown;
- It is prohibited to connect the battery with different type of battery;
- It is prohibited to put the batteries working with faulty or incompatible inverter;
- In case of fire, only dry powder fire extinguisher can be used, liquid fire extinguishers are prohibited;
- Please do not open, repair or disassemble the battery. We do not undertake any consequences or related responsibility due to violation of safety operation or violating of design, production and equipment safety standards.

3. Unpacking & Overview


3.1 Packing List

You will receive the following parts (Not a full set), sample as follow picture. For customized requirements, please place an order with the manufacturer.


| | | |
|---------------------------------|--------------------------|------------------------------|
| Battery Pack | Power out Negative cable | Power out Positive cable |
| | | |
| Parallel common cable | Desiccant | Mounting brackets (optional) |
| | | |
| Mounting frame screw (optional) | Manual (optional) | Warranty Card (optional) |
| | | |




3.2 Product Overview



| | Description | Silk-screen | Remark |
|----|-----------------|-------------------|--------------------------------------|
| 1 | Output terminal | + + | Output terminal |
| 2 | Output terminal | - - | Output terminal |
| 3 | Handle | | |
| 4 | LED indicate | RUN | Operation indicator |
| 5 | LED indicate | ALM | Alarm indicator |
| 6 | LED indicate | CAPACITY | Capacity indicator |
| 7 | LCD | | Touch screen or non touch screen |
| 8 | LCD Key | MENU/Enter/UP/ESC | |
| 9 | Power Switch | ON/OFF | |
| 10 | Reset button | RST | For reset the batter |
| 11 | Dial switch | ADS | Set the address |
| 12 | Dry port | DRY CONTACT | |
| 13 | RS485A Port | RS485A | RS485A and inverter connection port |
| 14 | CAN bus Port | CAN | CAN bus and inverter connection port |
| 15 | RS232 Port | RS232 | RS232 and computer connection port |
| 16 | RS485B Port | RS485B | battery and battery connection port |
| 17 | E-Switch | ON/OFF | |
| 18 | Wheel | | |



Wall Mounted Battery pack



Floor Mounted Battery pack

4. Installation

4.1 Selecting Mounting Location (Apply to Wall mounted product)

Consider the following points to install the energy storage Pack:

- Do not mount the Pack on flammable construction materials. Mount on a solid surface.
- Install this Pack module at eye level in order to allow the readability of LCD display at all times.
- For proper air circulation to dissipate heat, please leave a gap of about >0.3 meter from the ground, 30 cm from the side of the device.
- The ambient temperature should be between 0°C and 40°C and relative humidity should be between 25% and 85% to ensure optimal operation.
- The recommended installation is flat wise adherence.
- Install the battery module in a dry, protected area with no excessive dust and sufficient air circulation. Do not operate in locations where the temperature and humidity are outside the specified range.



4.2 Mounting The PACK (Apply to Wall mounted product)



WARNING!! Remember that this Pack is heavy so please be careful when removing it from the package, or install it


When installing the Pack bracket, use appropriate screws to fix it. After that, the equipment should be firmly bolted. The pack can be run indoors or outdoors. However, only professional personnel can enter this area for installation or maintenance.

Step 1:

- When receiving the product, first check whether all parts are complete, if not, please report to the Dealer.


Step 2:

- Ensure that the Pack is installed on the wall surface. Choose a suitable installation location and require the battery pack to be placed at a safe distance greater than 30cm from the ground, and the safety distance between battery packs is also greater than 30cm too. We recommend an installation distance is 50cm.




Step 3:

- Use the mounting bracket to mark the location of the positioning screw hole on the wall, and use an electric drill to drill the hole. Need to be drilled with a drill of appropriate diameter.




Step 4:

- Insert frame screws, then place the bracket, and use screws to lock it.




Step 5:

- As shown in the below, install the battery pack. The pack is too heavy, please use a special lifting device to lift the pack for operation and safety protection. Lift the pack and put it into the slot of the fixing bracket from the front. You can install more packs as shown.



Tips:

- When more than 3 PCS packs are connected in parallel, then we recommend you install a combiner box. 3 locations we recommend you install the combiner box. First select location is Top and Bottom, show as below.






4.3 Connection and Communication


Step 1 :

Connect the wiring of the Pack as shown below. See figure 11. If inverter need CAN BUS port/RS485B only be used for battery packs parallel mode.



CAN And RS485A---Communicate with external devices, sample as inverter ,EPS
RS232---Communication with host computer
RS485B---Communication with host computer or parallel communication with battery pack

1pack---1 Inverter. Single mode.




More pack are parallel, one pack is master, other are slave.

If your need a "3-phase inverter output 380VAC".


One inverter is master, other are slave.

Please refer to the operation manual of the inverter for the parallel connection method of the inverter, there is only an example.




Step 2:

Set the address of packs. This is an important step. Please set as the picture shows below. PACK 1 set as Master, and address "0" is only used for single mode. It supports 15 PCS pack(max) in parallel.



| 拨码地址位 | 说明 (Explain) | | | | |
|-----------|--------------|-----|-----|-----|---------------------|
| | 4 | 3 | 2 | 1 | |
| 0000 (0) | OFF | OFF | OFF | OFF | 单机使用single mode |
| 0001 (1) | OFF | OFF | OFF | ON | 设置 PACK1 (主机MASTER) |
| 0010 (2) | OFF | OFF | ON | OFF | 设置 PACK2 |
| 0011 (3) | OFF | OFF | ON | ON | 设置 PACK3 |
| 0100 (4) | OFF | ON | OFF | OFF | 设置 PACK4 |
| 0101 (5) | OFF | ON | OFF | ON | 设置 PACK5 |
| 0110 (6) | OFF | ON | ON | OFF | 设置 PACK6 |
| 0111 (7) | OFF | ON | ON | ON | 设置 PACK7 |
| 1000 (8) | ON | OFF | OFF | OFF | 设置 PACK8 |
| 1001 (9) | ON | OFF | OFF | ON | 设置 PACK9 |
| 1010 (10) | ON | OFF | ON | OFF | 设置 PACK10 |
| 1011 (11) | ON | OFF | ON | ON | 设置 PACK11 |
| 1100 (12) | ON | ON | OFF | OFF | 设置 PACK12 |
| 1101 (13) | ON | ON | OFF | ON | 设置 PACK13 |
| 1110 (14) | ON | ON | ON | OFF | 设置 PACK14 |
| 1111 (15) | ON | ON | ON | ON | 设置 PACK15 |



| 接口 Connector | RS485-1 | | CAN1 | | RS323 | | RS485-2 * 2 | |
|------------------------|---------------------------------|-------------|---------------------------------|-------------|----------------------|-------------|-----------------------------------|--------------|
| 功能描述 Function | 连接上位机或逆变器 (Connected PC or PCS) | | 连接上位机或逆变器 (Connected PC or PCS) | | 连接上位机 (Connected PC) | | 并机通信 (Parallel communication) * 2 | |
| 引脚说明 Pin specification | PIN | Description | PIN | Description | PIN | Description | PIN | Description |
| | 1、8 | RS485-B1 | 1、8 | NC | 1、2、6 | NC | 1、8 | RS485-B2 |
| | 2、7 | RS485-A1 | 2、7 | NC | 3 | TX | 2、7 | RS485-A2 |
| | 4 | NC | 4 | CANH1 | 4 | RX | 4、5 | NC |
| | 5 | NC | 5 | CANL1 | 5 | GND | 3 | IN(L)/OUT(R) |
| | 3、6 | GND | 3、6 | GND | | | 6 | GND |


- NOTE: Rs232 port used for host software and update the firmware.
- NOTE: The all-in-one products will not need to connect power cables and communication cables
- NOTE: The output connected to the communication cable with a waterproof plug is listed according to the order requirements, which are customized products, and are not listed here.



Step 3: Power on and set protocol

Confirm that the operation is correct, and the battery function can be turned on after the wiring is correct. Running the device, set the external charger or inverter parameters, please set according to the product spec. Can not exceed the rated parameter requirements.


Touch screen version



a.Login to account here, Password:666888

b.Select the Protocol here. Sincere suggest purchasing inverters together from our factory. We will set up the protocol before leaving the factory to reduce your installation trouble.

Keypad version



Operate as shown in the above picture. Sincere suggest purchasing inverters together from our factory. We will set up the protocol before leaving the factory to reduce your installation trouble.



When it is necessary to stop the charging and discharging of the battery or troubleshooting, please stop the external equipment first, cut off the input and output circuits, and then press the power switch off each battery pack.




Battery Pack support communication with inverter: (More communication protocols need to be proposed separately)

| 逆变器品牌 Brand of inveter | 协议名称 Protocol | 通讯方式 Communication method | 是否配对过 |
|---------------------------|---|------------------------------|-------|
| 派能 PYLONTECH | RS485-protocol-pylon-low-voltage | RS 485-9600 | OK |
| | CAN-Bus-protocol-PYLON | CANBUS-500K | OK |
| 固德威 GOODWE | 固德威通讯协议 | CANBUS-500K | OK |
| 古瑞瓦特 Growatt | SPF BMS RS485协议 | RS485-9600 | OK |
| | Growatt BMS CAN-Bus-protocol-low-voltage(SPF) | CAN | OK |
| SMA | FSS-ConnectingBat-TI-en-20W | CANBUS-500K | OK |
| Victron | can-bus_bms_protocol | CANBUS-500K | OK |
| TBB | TBB 锂电池BMS平台CAN 通讯协议V1.02 | CANBUS-500K | OK |
| MUST | MUST美世乐 1_PV1800F-CAN communication Protocol1.04.04 | CANBUS-100K | OK |
| 硕日 srne | PACE BMS Modbus Protocol for RS485 | RS485-9600 | OK |
| 迈格瑞能 MEGARUNO | 深圳迈格瑞能技术混合逆变器_5K_BMS协议V1.01 | CANBUS-500K | OK |
| 德业 Deye 德業 | RS485-protocol-pylon-low-voltage-新增协议设计-德业12号9600 | 485 | OK |
| | CAN-Bus-protocol-PYLON-v1.3 | CANBUS-500K | OK |
| 英威腾 invt 英威腾 | XN Inverter and BMS 485 communication protocol 20200325 | RS485-9600 | OK |
| 日月元 Voltronic Power | Voltronic Inverter and BMS 485 communication protocol | 9600 | OK |
| 首航 SOFAR 首航新能源 | Sofar-首航-CAN-V1.00-211117-Rev6 | CANBUS-500K | OK |
| 北京汇能精电 EPEVER | BMS-Link通讯协议 V1.4 | 9600 | OK |
| 佛山春夏秋冬 SVCEnergy | Invert_Modbus通信协议_中文版V1_4 | 9600 | OK |
| 鹏程 LUXPOWER | Luxpowertek Battery CAN Protocol | CANBUS-500K | OK |



Appendix 2


Parallel Connection




Appendix 3

Host soft operation:

When the equipment manufacturer confirms that it is necessary, It can authorize to provide the customer with the host software and operating instructions.




The connection method:
After installing the special driver for our communication box on the computer, insert the USB end of the communication box into the USB port of the computer, and connect the other end to the corresponding interface of the protection board that has been connected to the battery. Open the upper computer, click the communication port settings, select the COM port corresponding to the communication box, and do not change other options. After confirming, click Start to read the data from the BMS.





Appendix 4 Wifi&Bluttooth


Download the APP from the website below:
<https://cn.jiabaida.com/li-ion.html>



Appendix 5 Trouble shooting

1. Battery pack stop work.

- A: Turn on switch, be sure it is ON; If battery is low SOC, it need to charging in.
- B: Battery pack low volt or enter sleep mode,there you will press down "RST" button3-6 second,or charging in.



2. No communication ,inverter can not received any DATA from BMS.

- A: Check whether if communication cable is OK,check RJ45 PIN,
- B: Replace the communication line.Please give feedback to the dealer and exchange it.
- C: Check inverter or other device which connect to BMS,update it is firmware.
- D: If the communication function needs to be upgraded, please consult the agent or manufacturer.
- E: Confirm your inverter and battery protocol is correct,Different protocol or different connection will make a mistake.



3. Battery pack report SOC is mistake.

- A: Inverter received Data from Master BMS, but it is SOC < total SOC, sample as: 9PCS packs has 1800Ah, but inverter read DATA is 1600Ah. So you may check any one is disconnected.check RS485B communication cable(blue), RS485 communication cable, replace the cable which is broken.RJ45 PIN:
CAN: PIN4:CANH,
PIN5:CANL;
RS485A: PIN2:485-A,
PIN1:485-B;
- B: SOC DATA has Large tolerance.
Discharge empty the battery first, then charge it fully with a small current, and learn to discharge. Any pack ismistake, we advice you read the BMS Data(When we authorize the terminal to use) with host software.then we reset the BMS and calibration.
- C: When multiple batteries are connected in parallel, the SOC is different.
We recommend that each pack has a small current discharged and it is emptied until the SOC alarm appears, and then recharged in parallel and fully charged.

4. How to turn on the Pack todischarge.

- We recommend method is:
- A: Reset the single pack's BMS, LED will flash and startwork
- B: Turn on the power switch on the bottom/front panel;
- C: Turn on power switch in the combiner box.

WARNING: The operating parameters of the equipment cannot exceed the rated working voltage and current ofthe Pack, exceed the rated volt and current,Can cause damage to the Pack or other failures.

5. Inverter or other external device can not connect the battery.

- We recommend method is:
- A: Check whether the working parameter's of the device and battery are appropriate, and improper parameters cannot be matched.
- B: When the device is turned on, the current is too large, resulting in battery protection, At this time, you should beable to see the LED flashing from the battery panel.in this case, You can adjust your equipment parameters or contact the dealer to solve.
- C: It is necessary to update BMS parameters and match the device,then Reset BMS and restart your device.

6. Replace bad Pack.

There is a bad battery pack, it is need to replace, please connect your supplier, need professional installers to operate it. We recommend replace all or make pack has same voltage and same specification batteries pack.
NOTE: When replacing the battery, the same module needs to be replaced at the same time, and the voltage should be the same.

7. Need to replace spare parts or emergency maintenance.

Some parts can be obtained from the sales or agency, and the excess parts need to be purchased separately.
Be careful, turn off the power switch before replacing parts.

8. Need to place some safety device for keep a safe environment.

You'd keep a safe case for Pack and external device, Please place safety device, as: fire-fighting sand, fire-fighting blankets, fire-fighting water pipes, Install Monitor sound, light, electricity, smoke and other equipment.

WARNING:

Emergency process:

1. The external device catches fre and explodes:

- A: Under the condition of ensuring safety, non-operating personnel immediately move to a safe location.
- B: Under the condition of ensuring safety, the operator immediately cut off the external power supply of the equipment and the internal power supply.
- C: Use fire-fighting equipment for fire-fighting treatment (the use of fire-fighting sand, fire-fighting blankets, fire- fighting water pipes)
- D: If you cannot completely extinguish the fire, please call the local fre department for help.
- E: Keep the accident site data so that the source of the accident can be traced.

2. The Pack catches fre and explodes:

- A: Under the condition of ensuring safety, non-operating personnel immediately move to a safe location.
- B: Under the condition of ensuring safety, the operator immediately cut off the external power supply of the equipment and the internal power supply.
- C: Use fire-fighting equipment for fire-fighting treatment (the use of fire-fighting sand, fire-fighting blankets, fire- fighting water pipes)
- D: If you cannot completely extinguish the fire, please call the local fre department for help.
- E: Keep the accident site data so that the source of the accident can be traced.